
Effect return 2
Effect return 1
Mic insert
Mic 3
Mic 2
Mic 1
AC 230 Volts
315 ma Fuse
Send 2
Send 1
Music insert
Line 3
Earth
screw
L2 P2 L1 P1
Tape out
Tops
output
mids
output
low mid
output
bass
output